

PULSA Series®

DIAPHRAGM METERING PUMPS

ELMA CONTROLS

**INSTALLATION
OPERATION
MAINTENANCE
INSTRUCTION**


BULLETIN No. 421 Rv B



A Unit of IDEX Corporation

Manufacturers of Quality Pumps,
Controls and Systems

ENGINEERED PUMP OPERATIONS
2883 Brighton Henrietta TL Road
P.O. Box 22909
Rochester, New York, 14692-2909 USA
Telephone (716) 292-8000
Fax (716) 424-5619
<http://www.pulsa.com>



ATTENTION

Re-Calibration of this Electronic Actuator is required.

1. Although calibrated before leaving the factory, variations in input signals will require re-calibration prior to start-up. Refer to the Calibration Section of this manual for complete instructions.
2. This actuator is equipped with signal protection circuitry. Re-calibration will require changing the setting of the DIP switches which are a part of the protection system. Refer to the Protection Circuitry Section of this manual for complete instructions.

OPERATIONAL NOTICE

The ELMA electronic stroke actuator is designed to function only when the pump is operational. To ensure proper adjustment of pump stroke length, the actuator should operate only when the pump motor is also operating. Control systems should be designed to ensure that the actuator does not operate to change stroke setpoint when the pump is not operating. This can be accomplished by:

- 1) Removing power from the actuator when the pump motor is turned off.
- 2) Removing the mA input signal from the actuator when the pump motor is turned off, and setting the signal protection option to "freeze at last setting on loss of signal" as per table 1, page 12.

TABLE OF CONTENTS

	<u>PAGE</u>
MODEL CODE BREAKDOWN	5
INTRODUCTION	
GENERAL DESCRIPTION	6
STANDARD FEATURES	6
OPTIONAL FEATURES	6
PRINCIPLES OF OPERATION	
BASIC ACTUATOR	7
FEATURES	7
OPTIONS	7
INSTALLATION	
CHECK	8
WIRING INSTRUCTIONS	8
CALIBRATION	
MECHANICAL STOPS	8
COMPARATOR CIRCUIT	9
DEADBAND	10
METER READOUT	10
RATIO CONTROL	11
PNEUMATIC INPUT	11
PROTECTION CIRCUITRY	11
CONNECTION DIAGRAM	13
TROUBLE SHOOTING	14
REPAIRS	15
CONVERSIONS	15
SPECIFICATIONS	18
DRAWINGS	
NEMA 4 CROSS SECTION	19
NEMA 4 EXPLODED ISOMETRIC	20
NEMA 7 CROSS SECTION	21
NEMA 7 EXPLODED ISOMETRIC	22

MODEL CODE BREAKDOWN

SELECTING AN ELMA MODEL NUMBER (e.g. BEMDA-BP)

1	2	3	4	5
Pump Size	Actuator Type	Input Signal	Action	Power Requirement
B = 680	E = NEMA 4	C = 10-50 mA	D = Direct Action	A = 115v, 60 Hz
C = 880	W = NEMA 7	D = 1-5 mA	R = Reverse Action	C = 220v, 50 Hz
D = 200	Z = Special	M = 4-20 mA ⁽⁶⁾		

V = 1-5 VDC
 P = 3-15 psi NEMA 4 only⁽⁵⁾
 S = Split Range (50%; 4-20 or 12-20 mA)
 X = No Auto Signal
 Z = Special

6 OPERATOR STATION OPTIONS

(For Customer Mounting and Wiring)

- A = Manual Potentiometer (Follows pump mounted potentiometer signal only)⁽⁴⁾
- B = Manual Potentiometer w/Meter Readout ⁽²⁾⁽⁴⁾⁽⁷⁾
- C = Auto-Manual ⁽³⁾
- D = Auto-Manual w/Meter Readout ⁽²⁾⁽³⁾⁽⁷⁾
- E = Ratio Control
- F = Ratio Control w/Meter Readout ⁽²⁾⁽⁷⁾
- G = Ratio Control w/Meter Readout and Auto-Manual ⁽²⁾⁽³⁾⁽⁷⁾
- H = Ratio Control w/Auto Manual ⁽³⁾
- X = No Option (Straight Automatic)
- Z = Special

7 OPERATOR STATION ENCLOSURES

- H = NEMA 4X Stainless, Rain/Moisture Tight/Corrosive Resistant Outdoor Pump Mounted⁽⁷⁾
- J = NEMA 4X Plastic, Rain/Moisture Tight/Corrosive Resistant, Pump Mounted⁽⁷⁾
- P = NEMA 4X Plastic, Rain/Moisture Tight/Corrosion Resistant⁽⁷⁾
- S = NEMA 4X Stainless, Rain/Moisture Tight/Corrosion Resistant (Outdoor)⁽⁷⁾
- X = No enclosure, Components only
- Z = Special

- Notes:**
1. For split range jobs, the order must specify whether the lower (e.g., 4-12 mA) or upper (3.g. 12-20mA) signal portion range is required, and also whether reverse action is needed. A very common application for this feature is for acid or alkali injection in response to a pH signal for neutralization jobs, where the lower range signal requires reverse action.
 2. Meter readout is for direct acting only.
 3. Auto-manual includes auto-manual switch and manual potentiometer, switch is non-shorting type.
 4. Option A and B in position 6 require Position 3 = X (no auto signal)
 5. 3-15 psi option not available on NEMA 7 actuators
 6. Option M also includes 4-20 mA output as standard.
 7. Operator station options with meter readout (Position B,D,F or G) are only available in NEMA 4X plastic enclosure (Position 7 - J or P). Meter is located inside the enclosure behind transparent cover. Meter does not have a NEMA rating.

INTRODUCTION

• GENERAL DESCRIPTION

The PULSA stroke length controller is an electromechanical control device which adjusts the output flow of a PULSA Series pump according to an external process control signal. The controller design provides a compact, integral to the pump servo amplifier configuration, which utilizes AC synchronous motor technology as the primary driver. The stroke length is linear and proportional (directly or indirectly, as chosen by the customer) to the input control signal. Likewise, the reference feedback signal which is provided for remote monitoring of actual stroke length position, is also linear and proportional. Control of stroke length can be done manually by using the electronic override switch and a hand knob. An external mechanical indicator is mounted directly on the controller to indicate percent of stroke length.

• STANDARD FEATURES

1. Input Signals:
4-20 mA @ 250 ohm
1-5 mA @ 1000 ohm
10-50 mA @ 100 ohm
1-5 vdc
2. 4-20 mA feedback output signal.
3. External stroke length indicator (mechanical).
4. Manual override provision (mechanical).
5. NEMA 4 or UL listed NEMA 7 enclosure design.
6. Integral actuator/servo amp design.
7. Signal loss detection circuitry.
8. Over signal protection.
9. 115 volt @ 60 Hz operation.
10. The input and output signals are isolated from the power supply **only**.

• OPTIONAL FEATURES

1. 3-15 PSI input signal @ 0 C.F.M.
2. Variable ratio control.
3. Reverse acting control (e.g., 4 mA = 100%, 20 mA = 0%).
4. Split-ranging.
5. 220 volt @ 50 Hz operation.
6. Specials — consult the factory for your special application.




FIGURE 1

PRINCIPLES OF OPERATION

• BASIC ACTUATOR

(Figure 1)

The ELMA, (Electronic Lost Motion Actuator) is a simple control system composed of a position sensing device, an electronic circuit and a mechanical interface. The position sensor determines the actual stroke length, while the circuitry determines whether to increase, decrease or remain the same, and the mechanical interface actually performs the work of changing stroke length.

The stroke length of a PULSA Series pump is determined by adjusting a screw. This screw (referred to as the adjusting shaft) has a travel of 10 turns over the span of stroke length. In the ELMA design, an AC synchronous motor is coupled to this adjusting shaft through a timing belt and gears, and is the means of adjusting stroke length.

Also connected to the adjusting shaft is a potentiometer which acts as a position sensing device. This potentiometer is mechanically coupled to the adjusting shaft via gears and a timing belt, and is limited to 10 turns. This limit is done mechanically by an adjustable collar and a stop on the adjusting shaft. The feedback potentiometer provides a voltage to the circuit board which corresponds to actual stroke length.

The circuit board's main function is to compare two analog signals to each other, and to determine whether to increase, decrease, or keep the same stroke length. The two analog signals come from the feedback potentiometer and from an external instrument. (Examples of this include flowmeters, PH meters, rheostats, and computers). The comparison dictates whether the two signals are greater than, less than, or equal, and turns on a mechanical relay to make the AC synchronous motor turn either clockwise, counter-clockwise, or stop.

The most common input signal is a 4-20 mA current signal. In order to compare "apples to apples", this current needs to be converted to a voltage so the circuit board can compare it to the voltage signal provided by the feedback potentiometer. This is done by a 250 ohm shunt resistor, which converts 4-20 mA to a 1-

5 volt signal. A 1-5 volt input signal can also be used by clipping this connection to the shunt resistor (Refer to Table 2 on Page 18). The voltage signal from the feedback potentiometer is adjustable through the "High Cal" and "Low Cal" trims, so that the feedback voltages and the input voltages are of comparable voltage magnitudes.

TABLE 2

Signal Input Selection (Jumpers)

Input	Terminals	J4	J5	J6	J7
1-5 V	1 & 3	—	—	—	Out
1-5 mA	1 & 2	Out	Out	In	In
4-20 mA	1 & 2	Out	In	Out	In
10-50 mA	1 & 2	In	Out	Out	In
Remote	Auto Manual	—	—	—	Out

• FEATURES

CURRENT OUTPUT SIGNAL

A 4-20 mA output signal is provided for remote monitoring of stroke length. This signal is generated by a voltage to current converter which is driven directly by the feedback potentiometer. This source can drive an impedance of up to 250 ohms. The range of the current outputs are adjustable on the circuit board by adjusting the zero and span trim potentiometers.

MANUAL OVERRIDE

By moving the manual override switch to the manual position, stroke length control can be accomplished by hand turning the micrometer knob.

SIGNAL LOSS DETECTION

The circuit board can be configured such that if a loss of input signal occurs, it will maintain the stroke length at the position of the last given signal OR drive the stroke length to zero.

OVER SIGNAL PROTECTION

The circuit board disregards out-of-range signals which can lead to problems with overdriving.

NEMA 7

UL listed enclosure for Class I Groups C & D.

• OPTIONS

PNEUMATIC INPUT SIGNAL

This option allows the use of a 3-15 PSI pneumatic input signal to control stroke length. An integral pressure transducer converts the pneumatic signal to a 1-5 V voltage signal, thus controlling stroke length.

RATIO CONTROL

This option establishes a "ratio" between the input signal and resulting stroke length. This ratio can range from 100%:100% to 100%:0%. The ratio is infinitely adjustable over this range by adjusting a remote potentiometer.

SPLIT RANGING

The split-ranging option provides full actuator response over one half the input signal range. Response can be set for the lower or upper half of the signal range and can be direct or reverse acting.

INSTALLATION

• CHECK MODEL NUMBER

Check the ELMA model number breakdown for proper power supply connection. The model number, as well as the pump serial number, should be referred to for locating the proper wiring diagram, parts list and installation drawings. This information will describe the various options with which your electric actuator, and the pump have been supplied and show you where to make external connections for power, signal and other control options.

• WIRING INSTRUCTIONS

It is important that AC power for the ELMA unit be delivered in a separate conduit from the process signal or wiring for optional accessories. A separately switched, and protected circuit is recommended for the actuator power supply. Wiring the actuator in parallel with other devices (i.e. pump motor) can result in damage to the circuitry.

Remove the actuator cover, which is held on by 7 screws, or screwed on as on NEMA 7, to expose the actuator wiring connection terminals. There are 3 #18 gauge wires provided for the AC power connection. These wires, approximately 12" long, are color coded for ease of installation. An in-line fuse is provided for protection.

Note: Explosion proof actuators are Underwriters Laboratories (UL) listed and are labelled with the hazardous environments for which they are rated, along with any special installation specifications required in support of UL listing. They must be installed, wired, operated, and maintained in accordance with local electrical codes.

Run the signal and accessory wiring using the second conduit fitting. An 22 AWG wire size or larger is recommended. Twisted and shielded conductors can do much to reduce noise problems. Make all connections as per the diagram that applies to the combination of signal and accessories provided. Leave the actuator cover off for calibration.

CALIBRATION

Before shipment all actuators are calibrated to provide proper response to the input signal specified at the time of order. However, after installation, it is recommended that the unit be re-calibrated to compensate for any difference between factory and field conditions.

All actuators built after 3/89 utilize a revised circuit board, Part #W210412-000 (Fig. 3), while units built prior to this date use Part #W208641-000 (Fig. 4). The revised circuit board incorporates several new features including programmable signal loss and over signal protection. To facilitate calibration, this feature must be disabled. If your unit uses the revised circuit board, refer to the Section on Protection Circuitry before proceeding.

• MECHANICAL STOPS

(Figure 1 & 7)

1. Loosen setscrews on front and rear mechanical stops.
2. Turning worm shaft, position crosshead at full forward extension.
3. Thread adjustment shaft up to piston leaving a gap between the piston and crosshead of .002 inches.
4. Slide front mechanical stop forward until it is tight against the gearbox wall. Secure in place with setscrews.
5. Note position of dial counter. Turn adjustment shaft clockwise 10 times.
6. Slide rear mechanical stop back against bushing. Secure in place with setscrews.
7. Loosen knob and duo-dial.

8. Reset dial to 10 and secure with setscrew.

NOTE: Pumps with stroke length of .375" will need 7.5 on the dial at 100% stroke setting.

9. Position knob lining up long marks on knob with numbers on dial. Secure in place with setscrews.
10. With override switch in manual position, rotate adjustment shaft to 0% stroke and then to 100% stroke. This will position the feedback potentiometer to allow calibration of ELMA.

• **COMPARATOR CIRCUIT**
(See Figures 3,4 & 5)

CALIBRATION

If equipped with pneumatic input refer to that section for calibration. If equipped with ratio control use one of the following procedures but perform all adjustments at 100% ratio setting.

1. Comparator calibration procedure to be used with units supplied for AUTO control from a remote process signal.
 - a. With the override toggle switch in the "MAN" position wire the actuator per the supplied wiring diagram.
 - b. Locate the negative lead of a voltmeter to TB1-1 and the positive lead to TB1-3.
 - c. With the voltmeter in the DC mode measure and record the voltage across TB-1 and TB-3 at 0% and 100% process signal.
Ex: 4mA process signal \approx 1VDC
20mA process signal \approx 5VDC
 - d. Remove the process signal from the board.
 - e. Manually adjust the micrometer hand knob to 0% stroke setting.
 - f. Locate the positive lead of the voltmeter to the wiper terminal (black lead) of the feedback potentiometer while the negative lead is on TB1-1. Adjust the "Low Cal" potentiometer so that the wiper voltage equals that read in Step C at 0% process signal.
 - g. Manually turn the hand knob to the 100% setting and adjust the "High Cal" trim potentiometer so that the wiper voltage now equals that read in Step C at 100% process signal.

- h. Repeat Steps f and g until the voltages from the feedback wiper are stabilized to match the respective voltages read from Step C.
- i. Reconnect the process signal and place the override toggle switch to Auto position. Verify proper operation. If the actuator fails to fully adjust to either endpoint or does not switch off, then readjust the "Low" or "High Cal" trim potentiometer depending on which endpoint is off, until proper adjustment is achieved.

REMOTE AUTO/MANUAL CALIBRATION

2. Comparator calibration procedure to be used with units supplied for MANUAL control from a remote manual potentiometer or units supplied for AUTO/MANUAL control from a remote process signal and remote manual potentiometer.
 - a. With the override toggle switch in the "man" position wire the actuator and remote enclosure per the supplied wiring diagram.
 - b. For AUTO/MANUAL units turn the remote control switch to the "auto" position.
 - c. Perform Steps b-i as outlined in Procedure 1). For MANUAL units substitute a signal generator in place of the process signal.
 - d. Place both the override toggle switch and remote control switch in the "man" position.
 - e. With the manual stroke adjustment potentiometer at 0% measure the voltage across TB1-1 and TB1-3. Adjust the "Low" trim potentiometer on the back of the remote potentiometer assembly until the measured voltage equals that measured in Step 1-c at 0% process signal.
 - f. Turn the manual stroke adjustment potentiometer to 100%. Now adjust the "High" trim potentiometer on the back of the potentiometer assembly until the voltage across the TB1-1 and TB1-3 equals that measured in Step 1-c at 100% process signal.
 - g. Repeat Steps e and f until the measured voltages are stabilized to match the respective voltages read from Step 1-c.




FIGURE 3, W210412-000




FIGURE 4, W208641-000

• **DEADBAND**
(See Figures 3 & 4)

Adjustment of the deadband determines how closely the comparator circuit will attempt to match the feedback signal to the input signal. It provides a "window" of acceptable voltage tolerances.

Example:

If the deadband is too loose the comparator circuit is not as sensitive to signal change and may not fully adjust to the change of an input signal.

If the deadband is too tight the comparator circuit may constantly "hunt" causing erratic actuator movement with no change to the input signal.

Dead band adjustments are preset at the factory. If adjustments to the deadband have been unsuccessful you can go back to factory preset by turning the trim potentiometer screw ten times (CCW) "counter-clockwise" then one turn (CW) "clockwise".

• **METER READOUT**
(See Figures 3 & 4)

h. Place the override toggle switch in the "auto" position. Verify proper operation of the controller through the stroke adjustment potentiometer. If the actuator fails to fully adjust to either endpoint or reaches one endpoint and does not switch off, then readjust the "Low" or "High" trim potentiometer on the back of the potentiometer assembly depending on which endpoint is off, until proper adjustment is achieved.

- a. Put a proper load and/or meter across TB1-7 as (+) and with TB1-8 as (-), for a 4-20 mA signal.
- b. With the micrometer hand knob at 0%, adjust the zero adjust so that 4 mA is output from the circuit and/or meter reads minimum.
- c. With the micrometer hand knob at 100% adjust the span adjust so that 20 mA is output from the circuit and/or meter reads maximum.
- d. Repeat steps b and c until 4-20 mA is output from the circuit when 0% and 100% is dialed in and/or meter reads minimum and maximum.

• RATIO CONTROL

Due to highly toleranced components no adjustments are necessary.

• PNEUMATIC INPUT

(See Figure 5)

- a. With the override toggle switch in the "man" position wire the actuator per the supplied wiring diagram.
- b. Connect the negative lead of a voltmeter to TB1-1. This point is a circuit board common.
- c. Locate the positive lead of a voltmeter to J6 of the option board.
- d. Input a 3 PSI signal into the 1/4" NPT port and adjust the zero adjust until a 1 volt reading is obtained.
- e. Input a 15 PSI input and adjust the span adjust on the option board until a 5 volt reading is obtained.
- f. Repeat Steps d and e until a 1-5 volt range is obtained while inputting a 3-15 PSI signal.
- g. Remove the pneumatic signal from the board and place the override toggle switch in the "remote" position.
- h. Locate the positive lead of the voltmeter to the wiper terminal (black lead) of the feedback potentiometer.
- i. With the micrometer hand knob at the 0% stroke setting adjust the "Low Cal" trim potentiometer until a 1 volt reading is obtained.
- j. Turn the knob to the 100% setting and adjust the "High Cal" trim potentiometer until a 5 volt reading is obtained.
- k. Repeat Steps i and j until the voltages from the feedback wiper stabilize at 1 and 5 volts.
- l. Reconnect the pneumatic signal and place the override toggle switch to auto. Verify proper operation. If the actuator fails to full adjust to either endpoint or reaches an endpoint and does not switch off then readjust the "Low" or "High Cal" trim potentiometer depending on which endpoint is off, until proper adjustment is achieved.

• PROTECTION CIRCUITRY

The signal protection circuitry determines how the actuator responds in the event of a loss of signal or oversignal condition. Once the unit has been calibrated to a specific input signal it recognizes any signal which is less than the calibrated low end signal as a loss of signal and any signal greater than the calibrated high end signal as an oversignal. Responses are determined by the setting of the 3 position DIP switch (see Fig. 3). During calibration the circuit may see under or over signals and therefore the protection feature must be turned off for proper adjustments to be made. Table 1 illustrates how the DIP switch settings relate to the different modes.

Re-calibration will require changing the setting of the dip switches to the open position (refer to Table 1, Function 1).




Figure 5, W208814-001

TABLE 1
DIP SWITCH SETTINGS

(Figure 3)

FUNCTION	SWITCH POSITION		
	S1	S2	S3
1. Calibration Mode, Protection Disabled	Open	Open	Open
2. Drive to Zero on Loss of Signal	Closed	Open	-
3. Freeze at Last Setting on Loss of Signal	Open	Closed	-
4. Over Signal Protection	-	-	Closed

NOTE: 1. If both S1 and S2 are closed Function 3 will be active.
 2. '-' signifies switch can be in either position for that function.
 3. Set switches by depressing the appropriate side with a straightened paper clip or similar object. Depressing side marked "OPEN" will open the switch, depressing the other side will close it.




FIGURE 6
 TYPICAL CONNECTION DIAGRAM
 REFER TO WIRING DIAGRAM SUPPLIED WITH
 PUMP FOR ADDITIONAL INFORMATION

TROUBLESHOOTING

PROBLEM	PROBABLE CAUSE
Actuator Does Not Adjust	<ol style="list-style-type: none"> 1. No AC power to actuator. 2. Pump not running. 3. Override switch no in Auto position. 4. Control signal off, incorrect, or of inverted polarity. 5. Ratio control (if so equipped) set at or very near zero percent. 6. Blown fuse. 7. Wiring discontinuity. 8. Defective feedback potentiometer. (See "Repairs"). 9. Circuit board malfunction. 10. Broken drive belt.
Actuator Adjusts to Incorrect Setting	<ol style="list-style-type: none"> 1. Control signal incorrect or of inverted polarity. 2. Incorrect ratio control setting (if so equipped). 3. Circuit board out of calibration (See "Calibration"). 4. Meter readout out of calibration (if so equipped). (See "Calibration"). 5. Actuator misaligned to pump. (See "Repairs"). 6. Defective feedback potentiometer. (See "Repairs"). 7. Circuit board malfunction.
Actuator Adjusts in One Direction Only	<ol style="list-style-type: none"> 1. Control signal incorrect or of inverted polarity. 2. Incorrect ratio control setting (if so equipped). 3. Wiring discontinuity. 4. Defective feedback potentiometer. (See "Repairs"). 5. Circuit board malfunction.
Erratic Operation	<ol style="list-style-type: none"> 1. Wiring discontinuity. 2. Narrow deadband. (See "Calibration"). 3. Erratic control signal. (See "Deadband"). 4. Noisy control signal (check grounding and shielding of control signal leads). 5. Defective feedback potentiometer. (See "Repairs"). 6. Circuit board malfunction.

REPAIRS

• POTENTIOMETER

1. Remove P3 connector from circuit board.
2. Verify full potentiometer resistance of approximately 1000 ohms between pins 2 and 3.
3. A needle type (analog) meter is recommended for checking potentiometer operation. As the potentiometer gear is turned counter clockwise (as seen from the gear end), the resistance between pins 1 and 2 should vary uniformly from zero to approximately 1000 ohms.

As the potentiometer gear is turned clockwise (as seen from the gear end), the resistance should vary uniformly from approximately 1000 ohms to zero.

4. If the extreme readings vary significantly from zero to 1000 ohms respectively or if the resistance variation with rotation is not smooth at any point, the potentiometer should be replaced. If the directions of rotation are the reverse of those stated above, then the potentiometer has been wired for reverse acting operation.
5. To replace the potentiometer assembly, pre-set the pump stroke indicator to the "050" (50%) setting. Use a meter as described above to set the resistance of the potentiometer to 500 ohms, which represents mid-scale.
6. Install the potentiometer carefully without rotating or changing the position. Reconnect P3 to the circuit board.

• ZERO ADJUST ON DUO DIAL

See "Mechanical Stops", pages 5 and 6.

• CONVERSION

To convert a manual control 200, 680 or 880 pump to ELMA control, the following assemblies are required:

1. Conversion Kit and actuator.

2. Option Kit As Required

- Ratio Control Option - W208946-000
- Pressure Control Option - W208947-001 (for NEMA 4 actuator only)
- Pressure Control with Ratio Option - W208947-002 (for NEMA 4 actuator only)
- Split Range Control Option - W209725-001

Check to make sure you have the appropriate assemblies before beginning the conversion.

Note: Loosely tighten screws. Perform final tighten during mechanism adjustment unless otherwise specified:

A. REMOVAL OF MANUAL CONTROL

1. Remove cover and drain gearbox.
2. Unthread nut, sleeve and jam nut. Unthread the adjustment shaft and pull out from gearbox. Note: Adjustment shaft is left handed.
3. Carefully pull barrel indicator and bushing off at gearbox if not removed in Step 2.
4. Remove reagent head assembly, pump head assembly and cross head (Models 200 and 680 only) from gearbox.
5. Remove pump from base.
6. If the adjustment shaft hole diameter in the gearbox measures $.625 + 000/-001$ proceed to Section C "Preparing Gearbox for ELMA Mounting".

B. MACHINING GEARBOX


1. With table indicated perpendicular to machining head clamp gearbox to table with head end down.
2. With indicator, locate machining head to center of adjustment shaft hole in gearbox.
3. Bore adjustment shaft hole, to $.625 + 000/-001$ diameter.
4. For Model 880 gearboxes, inside spotface must be 1.00" diameter. (Optional 1.00 wide mill cut centered on adjustment shaft hole acceptable).

C. PREPARING GEARBOX FOR ELMA MOUNTING (Figure 7 & 8)


1. Press bushing into gearbox with flange to the inside. Note: Insert O-ring in bushing before pressing into gearbox.
2. Feed adjustment shaft through bushing into gearbox, threaded end first.
3. Slide rear mechanical stop onto adjustment shaft. See Fig. 7 Place 2 #8-32 set screws 90 degrees apart prior to assembly.

4. Slide front mechanical stop onto adjustment shaft. (Place 2 #8-32 setscrews 90 degrees apart prior to assembly).
5. Thread adjustment shaft into gearbox. Note: Adjustment shaft is left handed.
6. Slide adjustment shaft extension over adjustment shaft and into bushing.
7. For NEMA 7, skip to D.

CONVERSION KIT					
PUMP MODEL		ASSEMBLY NUMBER			
200, 680		W210294-680			
880		W210294-880			
ACTUATOR ASSEMBLY					
MODEL	STROKE	CYCLES	ACTUATOR ASSEMBLY NUMBER NEMA4	ACTUATOR ASSEMBLY NUMBER NEMA7	
680 AE	3/8	60 Hz	W210210-001	W210502-001	
680 AE	3/8	50 Hz	W210210-003	W210502-003	
680 AE	1/2	60 Hz	W210210-000	W210502-000	
680 AE	1/2	50 Hz	W210210-002	W210502-002	
680 AP	3/8	60 Hz	W210234-001	-----	
680 AP	1/2	60 Hz	W210234-000	-----	
680 AP	1/2	50 Hz	W210234-002	-----	
880 AE	5/8	60 Hz	W210210-000	W210502-000	
880 AE	5/8	50 Hz	W210210-002	W210502-002	
880 AP	5/8	60 Hz	W210234-000	-----	
880 AP	5/8	50 Hz	W210234-002	-----	



**FIGURE 7
CONTROL ROD ASSEMBLY**



**FIGURE 8
ELMA BRACKET N4/N7**

8. Locate template provided over shaft extension and worm shaft. Mark 4 mounting hole centers. (Note: There are 8 holes in template. Only use 4 holes indicated in Fig. 8 for model pump being converted).
9. Remove template. Drill and tap #10- 32UNF-2B through at locations marked in Step 7.
10. Flush gearbox to remove all chips from inside gearbox.

D. ASSEMBLY OF ELMA CONTROL

1. Reinstall crosshead, pumphead and reagent head assembly.
2. Holding rear mechanical stop against bushing, push adjustment shaft extension forward until it hits the stop. Slide nylon washer, over shaft extension. Slide timing gear over shaft extension forward to gearbox. Secure timing gear in place with 2 #8-32 setscrews spaced 90 degrees apart.
3. Turning worm shaft, position crosshead at full forward extension.
4. Thread adjustment shaft up to piston leaving a gap between piston and crosshead of .002 inches.
5. Slide front mechanical stop forward until it is tight against the gearbox wall. Secure stop in place with setscrews.
6. Place reference marker on timing gear and gearbox. (Felt marker works best).
7. Slide rear mechanical stop back against bushing and secure in place with setscrews.
8. Pull timing gear and shaft extension from gearbox. (Check that nylon washer remains next to timing gear).
- 9a. NEMA 4 only, apply Permatex Form-A-Gasket to the 4 #10 filler head screws that mount ELMA bracket to gearbox. (Note: On 880 pumps place seal spacer washers on top 2 screws between gearbox and mounting plate). Mount bracket to gearbox.
- 9b. NEMA 7 only mount actuator and gearbox on base.
10. With nylon washer still next to timing gear slide shaft extension back into gearbox.
11. Place second nylon washer on shaft extension against the timing gear.
12. Position timing belt over gear, pinion, and adjuster as shown in Fig. 8.
- 13a. NEMA 4 only, install belt guard and bracket. Space upper standoff #8 flat washer between bracket and standoff to insure proper alignment of adjustment shaft extension.
- 13b. NEMA 7 only, install belt guard and bracket.
14. With the adjustment shaft at 100% stroke (fully retracted) set duo-dial at 10 and mount on shaft extension. (Be sure to position locking groove in dial over roll pin on bracket). Secure in place with setscrew provided.
15. Mount knob on shaft extension taking care to position long marks on knob with numbers on dial. Secure in place with 2 #6-32 setscrews spaced approximately 90 degrees apart.
16. Mount gearbox on base.

E. ADJUSTMENT OF ELMA CONTROL

1. With override switch in manual position, rotate adjustment shaft to 0% stroke, then to 100% stroke. This will position the feedback potentiometer to allow calibration of ELMA.
2. See Section on "Calibration Instructions for Adjusting Mechanism" for adjustment and assembly completion.

SPECIFICATIONS


NEMA 4 Actuator Enclosure
0-100% Stroke Length Indicator at pump
115V, 60Hz OR 220 v, 50 Hz, 1 Phase AC Supply
Signal Ranges: 4-20mA dc @ 250 OHM Impedance
1-5 v dc GREATER THAN 270,000 OHM
3-15 psi Instrument Air
Dead Band Adjustment form 0.5% to 6.0%
15 Sec. Max Response Time for 0-100% Change
Micrometer Manual Override with Override Switch
Output Signal: 4-20mA dc
Operating Temperature Range: -25° to +65°C

Outstanding Features

NEMA 4 moisture tight or NEMA 7 explosion proof
(Class 1, Division 1, Group C + D actuator enclosure)
Manual override with override switch — Standard
0-100% stroke length indicator at pump — Standard
High Resolution Servo-Amp built into actuator — no separate cabinet required.
15 Sec Max. response time for 0-100% change
Power consumption is only 60 watts
Compact space saver design
Electric (standard) or pneumatic (option) signal capability
Circuit board drives at 4-20mA signal for "handshake" (control interface) mode
Signals completely isolated form AC supply
Closed loop control system utilizes AC synchronous motor technologies
Can operate under continuous stall or without signal without damage
Plug capability for ratio control
Design allows easy field conversion

Available Options

Explosion Proof
Special Signals — Reverse Action, Split Range
Controls — Electric Manual, Auto-Manual, Meter Readout, 0-100% Ratio
Control Enclosures — NEMA 7 Explosion Proof




MODEL 200/680/880-AE/AP
NEMA 4 ACTUATOR ASSEMBLY
ELMA CONTROL

ITEM	PART NAME	QTY
1	ENCLOSURE	1
2	ENCLOSURE GASKET	1
3	FILLISTER HEAD SCREW	1
4	MOUNTING BRACKET	1
5	HEX NUT	1
6	LOCK WASHER	1
7	MAIN CIRCUIT BOARD	1
8	CIRCUIT BOARD GASKET	1
9	STAND OFF	1
10	STAND OFF	1
11	STAND OFF	1
12	STAND OFF	1
13	STAND OFF	1
14	MOTOR ASSEMBLY	1
15	A C LINE ASSEMBLY	1
16	TIE RAP	1
17	FUSE	1
18	PINION GEAR	1
19	PINION GEAR SET SCREW	1
20	BEARING	2
21	FEEDBACK POT / SWITCH ASSY	1
22	FEEDBACK BRACKET ASSEMBLY	1
23	MOUNTING BLOCK	1
24	LOCK NUT	2
25	MOUNTING PLATE	1
26	CONDUIT SEAL	2

FIGURE 9

ITEM	PART NAME	QTY
27	ELBOW (AE)	2
28	ELBOW (AP)	1
29	ADAPTOR (AP)	1
30	TUBE FITTING (AP)	1
31	LOCK WASHER	1
32	FILLISTER HEAD SCREW	7
33	OVERLOAD LABEL	1
34	TIMING GEAR	1
35	TIMING BELT	1
36	BEARING	1
37	BELT ADJUSTER	1
38	FLAT WASHER	1
39	FILLISTER HEAD SCREW	1
40	FLANGED BEARING	1
41	ROLL PIN	1
42	STAND OFF	2
43	FLAT WASHER	6
44	BRACKET	1
45	BELT GUARD GASKET	1
46	BELT GUARD	1
47	CAP LUG	2
48	WARNING LABEL	1
49	FILLISTER HEAD SCREW	2
50	WIRING DIAGRAM LABEL	1
51	TOGGLE SWITCH BOOT	1
52	PRESSURE OPTION KIT (AP)	1

NOTES: 1. ITEMS 2, 21 AND 22 ARE SHOWN ON THIS SIDE OF PUMP FOR CLARITY.
 2. CROSSHEAD IS PART OF PUMP HEAD PISTON ASSEMBLY.




MODEL 200/680-AE/AP
 NEMA 4 ACTUATOR ASSEMBLY
 ELMA CONTROL

ITEM	PART NAME	QTY
1	GEARBOX SUB-ASSEMBLY	1
2	PIPEPLUG	2
3	FRONT STOP	1
4	SET SCREW	6
5	ADJUSTMENT SHAFT	1
6	REAR STOP	1
7	COVER GASKET	1
8	COVER	1
9	FILLISTER HEAD SCREW	4
10	ACTUATOR ASSEMBLY	1
11	FILLISTER HEAD SCREW	2
12	O RING	1
13	THRUST WASHER	2
14	TIMING GEAR	1
15	EXTENSION SHAFT ASSY	1
16	DUO-DIAL	1
17	ADJUSTMENT KNOB	1
18	SET SCREW	2
19	SET SCREW	2
20	CROSSHEAD	1
21	DRIVE SCREW	4
22	NAMEPLATE	1

MODEL 880-AE/AP
 NEMA 4 ACTUATOR ASSEMBLY
 ELMA CONTROL

ITEM	PART NAME	QTY
1	GEARBOX SUB-ASSEMBLY	1
2	PIPEPLUG	2
3	FRONT STOP	1
4	SET SCREW	6
5	ADJUSTMENT SHAFT	1
6	REAR STOP	1
7	COVER GASKET	1
8	COVER	1
9	FILLISTER HEAD SCREW	4
10	ACTUATOR ASSEMBLY	1
11	FILLISTER HEAD SCREW	2
12	O RING	1
13	THRUST WASHER	2
14	TIMING GEAR	1
15	EXTENSION SHAFT ASSY	1
16	DUO-DIAL	1
17	ADJUSTMENT KNOB	1
18	SET SCREW	2
19	SET SCREW	2
20	CROSSHEAD (SEE NOTE 2)	-
21	DRIVE SCREW	4
22	NAMEPLATE	1
23	C-RING CLIP	2
24	CONNECTING ROD	1
25	DIAPHRAGM GASKET	1
26	SUB COVER	1
27	HEX HEAD SCREW	4
28	THREAD SEAL	2
29	FILLISTER HEAD SCREW	2

FIGURE 10




MODEL 200/680/880-AE
NEMA 7 ACTUATOR ASSEMBLY
ELMA CONTROL

ITEM	PART NAME	QTY
1	DRIVE SCREW	4
2	NAME PLATE	1
3	ENCLOSURE	1
4	FILLISTER HEAD SCREW	2
5	FILLISTER HEAD SCREW	3
6	MAIN CIRCUIT BOARD	1
7	MOUNTING BRACKET	1
8	FLAT WASHER	2
9	HEX NUT	1
10	CIRCUIT BOARD GASKET	1
11	STAND OFF	5
12	STAND OFF	1
13	STAND OFF	3
14	STAND OFF	4
15	MOTOR ASSEMBLY	1
16	A.C. LINE ASSEMBLY	1
17	TIE RAP	1
18	FUSE	1
20	PINION GEAR ASSEMBLY	1
21	MOUNTING BRACKET	1
22	FEEDBACK POT ASSEMBLY	1
23	OVERRIDE SWITCH	1
24	CAP SCREW	2
25	MOUNTING BLOCK	1
26	STUD	4
27	O RING	1
28	MOUNTING PLATE ASSEMBLY	1
29	PIN	1
30	O RING	1
31	LABEL	1
32	SNAP RING	1
33	KNOB	1
34	RETAINING RING	1
35	TIMING GEAR	1
36	CAUTION LABEL	1
37	WIRING DIAGRAM LABEL	1

FIGURE 11

- NOTES 1. ITEMS 1, 37 AND 38 ARE SHOWN ON THIS SIDE OF PUMP FOR CLARITY
2. CROSSHEAD IS PART OF PUMPHEAD PISTON ASSEMBLY

THIS ASSEMBLY VIEW HAS BEEN ROTATED 35° FROM ITS ACTUAL POSITION FOR CLARITY




MODEL 200/680-AE N7
CONTROL ASSEMBLY
ELMA CONTROL

MODEL 880-AE N7
CONTROL ASSEMBLY
ELMA CONTROL

ITEM	PART NAME	QTY
1	PIPE PLUG	2
2	COVER GASKET	1
3	COVER	1
4	CAP SCREW	4
5	SET SCREW	2
6	FRONT STOP	6
7	FRONT ADJUSTMENT SHAFT	1
8	REAR STOP	1
9	O RING	1
10	GEARBOX SUB ASSEMBLY	1
11	BUSHING (COMPONENT OF ITEM 10)	1
12	ACTUATOR ASSEMBLY	1
13	MOUNTING WELDMENT	1
14	HEX HEAD BOLT	4
15	ROLL PIN	1
16	BEARING	1
17	BELT ADJUSTER	1
18	FLAT WASHER	1
19	FILLISTER HEAD SCREW	1
20	STANDOFF	2
21	FLAT WASHER	2
22	FILLISTER HEAD SCREW	2
23	CAP LUG	2
24	SET SCREW	2
25	SET SCREW	2
26	CONTROL KNOB	1
27	DUO-DIAL	1
28	BELT GUARD	1
29	BELT GUARD GASKET	1
30	EXTENSION SHAFT ASSEMBLY	1
31	BRACKET	1
32	FLANGED BEARING	1
33	TIMING GEAR	1
34	THRUST WASHER	2
35	TIMING BELT	1
36	CROSSHEAD	1
37	NAMEPLATE	1
38	DRIVE SCREW	4
39	FLAT WASHER	4
40	CLEVIS PIN	1
41	C-CLIP	2
42	SUB-COVER GASKET	1
43	SUB-COVER	1
44	SELF TAPPING SCREW	4

ITEM	PART NAME	QTY
1	PIPE PLUG	2
2	COVER GASKET	1
3	COVER	1
4	CAP SCREW	4
5	SET SCREW	2
6	FRONT STOP	6
7	FRONT ADJUSTMENT SHAFT	1
8	REAR STOP	1
9	O RING	1
10	GEARBOX SUB ASSEMBLY	1
11	BUSHING (COMPONENT OF ITEM 10)	1
12	ACTUATOR ASSEMBLY	1
13	MOUNTING WELDMENT	1
14	HEX HEAD BOLT	4
15	ROLL PIN	1
16	BEARING	1
17	BELT ADJUSTER	1
18	FLAT WASHER	1
19	FILLISTER HEAD SCREW	1
20	STANDOFF	2
21	FLAT WASHER	2
22	FILLISTER HEAD SCREW	2
23	CAP LUG	2
24	SET SCREW	2
25	SET SCREW	2
26	CONTROL KNOB	1
27	DUO-DIAL	1
28	BELT GUARD	1
29	BELT GUARD GASKET	1
30	EXTENSION SHAFT ASSEMBLY	1
31	BRACKET	1
32	FLANGED BEARING	1
33	TIMING GEAR	1
34	THRUST WASHER	2
35	TIMING BELT	1
36	CROSSHEAD (SEE NOTE 2)	1
37	NAMEPLATE	1
38	DRIVE SCREW	4
39	FLAT WASHER	4
40	CLEVIS PIN	1
41	C-CLIP	2
42	SUB-COVER GASKET	1
43	SUB-COVER	1
44	SELF TAPPING SCREW	4

FIGURE 12



PULSAFEEDER®
A Unit of IDEX Corporation

IDEX
IDEX CORPORATION

